

® **Glutoclean**

Kitchen Grease Remover **Küchen Entfetter**

Description

Cleaner with highest grease-removing properties. Food-safe. For all surfaces in the kitchen.

Action

Eliminates greases of all sorts in the household. Removes all greasy films and greasy deposits without difficulty and food-safe. Even stubborn and burnt-in incrustations are instantly dissolved and hygienically removed. Acts instantly!

Scope of application

For application in kitchen and household. For all washable surfaces such as stove, extractor hood, work surfaces, tiles, kitchen cupboards and appliances. Can also be used for washable grease filters.

Application

Spray onto the contaminated surface and leave to soak for a short while. Collect the solute contamination using a cloth or sponge and rinse with warm water. If necessary, rework with a brush in cases of a particularly stubborn degree of contamination and rinse with water.

Please note

Test sensitive (e.g. high gloss lacquered) surfaces for compatibility on an inconspicuous area before starting the treatment.

Storage:

Store well sealed in a cool and dry place.

Technical data

- Density: 1.015 g/ml
- pH value: 10-10.5
- Appearance: liquid
- Odour: fresh

Article n°:

036502074

750 ml PE spray bottle

Please see the EU Safety Data Sheet for all safety-related data (EU-CLP).

